
AIR MOTORS RADIAL-PISTON TYPE M5-0.5HP Parts List



| NO | 名 稱 | 數量 | NO | 名 稱 | 數量 | NO | 名 稱 | 數量 |
|-----|---------------|----|----|----------------|----|----|----------------------|----|
| 1 | Casing | 1 | 10 | Connecting Rod | 5 | 20 | O-Ring | 5 |
| 2 | Valve Bushing | 1 | 11 | Piston Pin | 5 | 21 | Spring Washer | 20 |
| 3 | Bearing | 1 | 12 | Gasket | 5 | 22 | Screw | 20 |
| 4 | Shaft | 1 | 13 | Thrust Washer | 2 | 23 | Gasket | 1 |
| 5 | Oil Seal | 1 | 14 | Ring | 2 | 24 | Casing Cover | 1 |
| 6 | Snap Ring | 1 | 15 | Bearing | 1 | | Screw | 5 |
| 7 | Bearing | 1 | 16 | Crank Pin | 1 | | Air Through Screw | 1 |
| 8 | Snap Ring | 1 | 17 | Sleeve | 5 | 7 | Flange Mount | 1 |
| 9 | Piston | 5 | 18 | O-Ring | 5 | 28 | Foot Mount | 1 |
| 9-1 | Piston coil | 5 | 19 | Cylinder Cover | 5 | 29 | Silencer | 1 |